

DS Vision 3000 Tuning Unit

Quick Guide



This guide explains how to connect and operate the DS Vision 3000 Tuning Unit.

For Further information, see the full User Guide. The latest User Guide can be found on our website www.minicomdigitalsignage.com in the Support section.

1. Introduction

The Receiver Long / Line Splitters can be tuned either via the Service Utility, as explained in the DS Vision 3000 User Guide, or by using the Tuning Unit.

For tuning the Receiver turn the Tuning adjuster, using a small screwdriver.

2. Connect the Tuning Unit

Connect the Tuning Unit to the Receiver Long/Line Splitter Tuning port using the VAU cable supplied or any 6 wire telephone cable up to 10m long. Once connected, **Minicom DSV-3000** appears in the LCD.

3. Operating the Tuning Unit

1. Press the Menu key to repeatedly scroll between the following functions:
 - Preset tables
 - Red
 - Green
 - Blue
 - Luminance (Lum)
 - Equalization (Equ)
 - Save / ESC
2. Select the desired function and adjust it using the **up** and **down** arrow keys.
3. Once the adjustment is satisfactory, press the Menu key to scroll to the next function.

Downloading a video table

To download a preset video table:

1. Scroll to Preset tables
2. Use the arrow keys to browse through all the predefined tables.
3. When you reach the desired table, press the Menu key. MNU=SAVE appears in the LCD and the table downloads. During downloading the LCD message blinks.
4. After downloading one table, a different table can be selected and downloaded.

Saving and exiting

To save all settings in the Receiver Long or Line Splitter unit:

1. Scroll to Save / ESC
2. Press the **up** arrow to save all changes and exit or press the **down** arrow to disregard all changes and exit.